

HOIST PARTS MANUAL

<p>HOCABLE 7/8" X 75' 6 X 37 STEEL CABLE</p> 	<p>HOMACPAR4004 D1101 ROLLER AXEL PIN</p> 
<p>HOCYL6X79 6 X 79 CYLINDER 60,000 # HOIST</p> 	<p>HOMACPAR4008 4008 PIVOT BUSHING COLLAR</p> 
<p>HOCYL779 7 X 79 CYLINDER 75,000 # HOIST</p> 	<p>HOMACPAR4010 M1531 CABLE SHEAVE 10"</p> 
<p>HOFENDER HOIST FENDER PLASTIC POLY</p> 	<p>HOMACPAR4012 D10456 SHEAVE PIN FRT VERT</p> 
<p>HOMACPAR 4000 D12117 CYL MOUNT FRT</p> 	<p>HOMACPAR4013 4013 HOR SHEAVE PIN SUPPORT RI</p> 
<p>HOMACPAR 4002 D10296 ROLLER AXEL COLLAR</p> 	<p>HOMACPAR4014 D12161 HOR SHEAVE PIN FRONT</p> 
<p>HOMACPAR 4003 D12644 SIDE PIN (DONUT)</p> 	<p>HOMACPAR4015 D12645 REAR SIDE PIN AXEL 9"</p> 

HOIST PARTS MANUAL

<p>HOMACPAR4016 M1845 ROLLER W/ BUSHING</p> 	<p>HOMACPAR4032 D12385 SAFTY PIN TUBE</p> 
<p>HOMACPAR4020 D12138 3" COLLAR</p> 	<p>HOMACPAR4034 D12124 PIVOT AXEL TUBE</p> 
<p>HOMACPAR4022 4022 CYL PLATE COLLAR 3" LONG</p> 	<p>HOMACPAR4036 D10454 CABLE ROLLER</p> 
<p>HOMACPAR4024 D12572 UPPER CYL BASE PIN</p> 	<p>HOMACPAR4038 4038 CABLE ROLLER COLLAR</p> 
<p>HOMACPAR4026 D12387 SAFTY PIN</p> 	<p>HOMACPAR4040 D10481 CABLE ROLLER PIN</p> 
<p>HOMACPAR4028 D12122 REAR PIVOT AXEL</p> 	<p>HOMACPAR4044 D12118 ROD END SPACER</p> 
<p>HOMACPAR4031 D12427 SAFTY PIN LATCH PAD</p> 	<p>HOMACPAR4046 D12570 UPPER PIN BASE COLLAR</p> 

HOIST PARTS MANUAL

<p>HOMACPAR4050 4050 RR AXEL WELD ON</p> 	<p>HOMACPAR4067 D23623 RR HUB LH CLOSED END</p> 
<p>HOMACPAR4056 4056 PIVOT BUSHING WELD ON</p> 	<p>HOMACPAR4068 D23624 RR HUB RH OPEN END</p> 
<p>HOMACPAR4058 D10482 TOP SHEAVE COLLAR</p> 	<p>HOMACPAR4098 D12633 TRUCK CYL PIN V2 55" +</p> 
<p>HOMACPAR4060 D10301 ROLLER HUB TUBE</p> 	<p>HOMACPAR5000 D13666 3/4 X 23/8 ANCOR TUBE</p> 
<p>HOMACPAR4062 D21953 REAR ROLLER</p> 	<p>XHOPBSB 1/2 BUMPER SQUARE BRACE</p> 
<p>HOMACPAR4064 D23622 REAR ROLLER AXEL</p> 	<p>XHOPBSP 1/2 BUMPER SUPPORT PLATE</p> 
<p>HOMACPAR4066</p> 	<p>XHOPBVB BUMPER VERTICAL BRACE</p> 

HOIST PARTS MANUAL

<p>XHOPCB2V2 D10447 ¾ CROSS BRACE V2 LOWE</p> 	<p>XHOPCM D19409 ½ CYL MOUNT/ 90 BEND</p> 
<p>XHOPCB3 D10448 ¾ MIDDLE CROSS BRACE</p> 	<p>XHOPCMMP D13665 ½ CYL MOUNT MUSHROOM</p> 
<p>XHOPCB5 ½ FRONT CROSS BRACE</p> 	<p>XHOPCMPSM ½ CYL MT P SIDE MACK</p> 
<p>XHOPCFDSINT ½ CENTER FENDER BRKT INTERNA</p> 	<p>XHOPFB FENDER BRACE 3X3X313/4 TUBE C</p> 
<p>XHOPCFINTWS ½ CENTER FENDER BRKT- INTERN</p> 	<p>XHOP410CAP D12071 10GA 4 X 10 END CAP</p> 
<p>XHOPCFPSINT ½ CENTER FENDER BRKT INTERNA</p> 	<p>XHOPBCB BUMPER CROSS BRACE</p> 
<p>XHOPCH ¾ CABLE HOOK</p> 	<p>XHOPBDB ½ PL BUMPER DECKHEAD BRACE</p> 

HOIST PARTS MANUAL

<p>XHOPBEC BUMPER END CAP</p> 	<p>XHOPFMBR FENDER MNT BRACKET REAR</p> 
<p>XHOPBFB BUMPER FLOW BAR</p> 	<p>XHOPFPST FRONT PLATE SUPPORT TUBE</p> 
<p>XHOPBH ½ BUMPER HOOK</p> 	<p>XHOPFBR REAR FENDER BRACE 1 1/2 X 2 1/2 31</p> 
<p>XHOPBPCSP ¾ BOTTOM PUSH CYL SUP PLATE</p> 	<p>XHOPFS D17518 7/8 NOSE ROLLER STOPS</p> 
<p>XHOPFCM D10280 ¾ FRONT CROSS MEMBER</p> 	<p>XHOPGP ¾ GUIDE PLATE</p> 
<p>XHOPFMBF FENDER MOUNT BRACKET FRONT</p> 	<p>XHOPGPB D10283 ½ GUIDE PIN BAR</p> 
<p>XHOPFMBM FENDER MNT BRACKET MIDDLE</p> 	<p>XHOPHB D10284 5" GUIDE CHANNEL 91"</p> 

HOIST PARTS MANUAL

<p>XHOPHBS D10280 5" GUIDE CHANNEL 89"</p> 	<p>XHOPLBAR LIGHT BAR (REAR)</p> 
<p>XHOPHD D17774 HOSE DEFLECTOR</p> 	<p>XHOPLC D12573 REAR CAP / LEFT</p> 
<p>XHOPHHP 10GA HYDRAULIC HOSE PLATE</p> 	<p>XHOPLMR D16993 LEFT MAIN RAIL 10 X 4 X</p> 
<p>XHOPHPA ¼ HYDRAULIC PLATE ARMS</p> 	<p>XHOPLPB D20235 10GA LICENSE PLATE BRKT</p> 
<p>XHOPHSP D17390 ½ HOR SHEAVE EAGLE PL</p> 	<p>XHOPMFA D15973 MUD FLAP ATTACHMENT</p> 
<p>XHOPICCCP D10484 ½ INSIDE CYL CABLE CO</p> 	<p>XHOPPP D12105 1" PIVOT PLATE</p> 
<p>XHOPPP2M PINTLE PLATE 2 MACK—1" PLATE</p> 	<p>XHOPRMR D12094 RIGHT MAIN RAIL 10 X 4</p> 

HOIST PARTS MANUAL

<p>XHOPPPS D12104 1" PIVOT PLATE PETERBUILT</p> 	<p>XHOPRMRS ½ REAR PLATE - MACK</p> 
<p>XHOPPSP2 PROXIMITY SWITCH PLATE 2</p> 	<p>XHOPRPPC D12120 ¾ REAR PIVOT PIN COLL</p> 
<p>XHOPRB RATCHET BAR</p> 	<p>XHOPRPPW D12119 ¾ REAR PIVOT PIN WELD</p> 
<p>XHOPRC D19695 REAR CAP – RIGHT/</p> 	<p>XHOPRPS ¼ REAR PLATE SPACER- OK PLATE</p> 
<p>XHOPRH 7/8 RATCHET STRAP (HOOK)</p> 	<p>XHOPRPPS ½" SIDE PIN SUPPORT PLATE</p> 
<p>XHOPRLB ¼ REAR LIGHT BRACKET</p> 	<p>XHOPRSP D21952 ½ REAR ROLLER SUPPORT</p> 
<p>XHOPRT D12790 6 5/8 REAR TUBE—27"</p> 	<p>XHOPTBTL TANK/TOOL BOX LEGS (TUBE)</p> 

HOIST PARTS MANUAL

<p>XHOPRTC ½ REAR TUBE CAP</p> 	<p>XHOPVLCPB D12185 1" UPPER LIFT CYL PLAT</p> 
<p>XHOPSA3X3 ½ SHEAVE ASSY 3 X 3 PLATE</p> 	<p>XHOPVSPS D12160 ½ VER SHEAVE PIN SUPP</p> 
<p>XHOPSPWA A1965A SAFETY PROP WELDMNT GH</p> 	<p>XHOPVSS D17412 ½ VER SHEAVE SUP HELM</p> 
<p>XHOPSAWEL A1518 SHEAVE WELDMNT BARE</p> 	<p>XHOPWS D12192 ½ X 3 WEAR STRIP</p> 
<p>XHOPSP D10453 1 1/2 X 7" CYL PIN/SHEAVE</p> 	<p>XHOPTBMB TANK/TOOL BOX MOUNTING BRACKET</p> 